

ABL

Local RFID Mode

eM4 Controller Wallbox




Converting an eM4 controller or an eM4 group (controller / extender)to "Local RFID Mode" is only possible after the complete configuration via the ABL Configuration App.

- This switches off the backend connection and it is possible to teach in RFID cards directly in the controller wallbox.
- You can reach the SBC web admin in various ways, e.g. via a laptop, a tablet or a smartphone - description from page 8 onwards

Local RFID Mode – User Interface

ABL




The screenshot shows the ABL User Interface with the following details:

- Header:** ABL User Interface, Logged in as OWNER, Change role ▾.
- Top Navigation:** Overview (highlighted in green), Products, Connectivity, Operation (highlighted with a green box and circled with a green number 1), Maintenance.
- Sub-navigation:** General (highlighted in green), Group, About, Licenses.
- Content Area:** Info, Charging Station section.
 - Serial number Charging Station: 10325981
 - Serial number SBC: S016961A9
 - Chargebox ID: ABL_10325981
 - Software Version: 2.0p10

- 1 Switch to the "Operation" tab

Local RFID Mode

ABL



- 1 Switch to the operating mode "Local - RFID Mode"

*Alternatively, "Free Charging" can also be selected here
(Free Charging Mode)*

- 2 Save

Local RFID Mode

ABL

ABL User Interface

Logged in as OWNER Change role ▾

Overview Products Connectivity Operation Maintenance

General OCPP Configuration OCPP Settings Eichrecht Load Management Local RFID Mode 1


Local RFID Mode. Management of User List.

RFID - UID	Username	Outlets	Action
No entries found.			

2 Add RFID-Card Delete all

Export User List: Export

Import User List: Durchsuchen... Keine Datei ausgewählt. Import



- 1 Switch to the "Local - RFID Mode" tab
- 2 Click on "Add RFID-Card" and present the RFID card in front of the RFID reader of the wallbox



Local RFID Mode

ABL

ABL User Interface

Logged in as OWNER Change role ▾

Overview Products Connectivity Operation Maintenance

General OCPP Configuration OCPP Settings Eichrecht Load Management Local RFID Mode

Local RFID Mode. Management of User List.

The teaching card UID 0441943AF85680 was updated successfully.

RFID - UID	Username	Outlets	Action
No entries found.			

1 0441943AF85680 2 John Miller 3 1 Example: 1, 4, 6, 16 or space for the selection all outlets 4 ✓ X

Export User List: Export

Import User List: Durchsuchen... Keine Datei ausgewählt. Import

- 1 Card UID is read and displayed
- 2 Enter name for card (e.g. User name)
- 3 Enter the number of the charging point for which the RFID card is to be valid
 - e.g. 1 for chargepoint 1
 - 1,2,4 for chargepoint 1, 2 and 4
 - Space bar for all charging points
- 4 Click hook for saving

Local RFID Mode

ABL

ABL User Interface

Logged in as OWNER Change role ▾

Overview Products Connectivity Operation Maintenance

General OCPP Configuration OCPP Settings Eichrecht Load Management Local RFID Mode

Local RFID Mode. Management of User List.

Data was saved successfully.

RFID - UID	Username	Outlets	Action
0441943AF85680	John Miller	1	
043052CA4A6580	Jessica Miller	2	

Add RFID-Card Delete all

Export User List: 1 Export

Import User List: Durchsuchen... Keine Datei ausgewählt. 2 Import

Repeat the process until all cards have been taught in

- 1 List of RFID cards can be exported, e.g. to read them in again at another wallbox
- 2 A list of RFID cards can also be imported
→ Charging sessions can now be released with the corresponding cards

ABL User Interface

The screenshot shows the ABL User Interface with the following details:

- User status: Logged in as OWNER
- Header navigation: Change role ▾, Overview, Products, Connectivity, Operation, Maintenance (highlighted with a green box)
- Sub-navigation: System (highlighted with a green box), Diagnosis, Logs ▾
- Main content: Maintenance Functions
- Section: System Restart
- Soft reset: Description - Restart the application and drivers. The operating system will continue working. It will take up to 100 seconds until the application is accessible again. Button: Soft reset
- Hard reset: Description - Restart the complete system including operating system. It will take up to 150 seconds until the application is accessible again. Button: Hard reset (highlighted with a green box and labeled 1)

Switch to the
"Maintenance" tab and
"System" tab

- 1 Click on "Hard reset".
Controller restarts

The "Local RFID mode"
function is then ready for
operation

ABL

Access options to the web admin


eM4 Controller



Access to the web admin of the controller wallbox


ABL

Wired via Router




Variant 1:

- Connection via network cable to a free port of the Routers
→ Input in the address field of a browser:
`ablserialnumber.local`



Variant 2:

- Select the WiFi of the wallbox – connect – enter password*



→ Input in the address field of a browser:
`10.10.10.200`

Variant 3:

- Read out the IP address via the router interface




→ Enter the IP address in the address field of a browser

* WiFi password of the wallbox (assigned during commissioning)

Access to the web admin of the controller wallbox


ABL

Wired via Switch (without Router)
DHCP through controller




Variant 1:

- Connection via network cable to a free port on the switch
→ Input in the address field of a browser :
ablserialnumber.local



Variant 2:

- Select the WiFi of the wallbox – connect – enter password*




→ Input in the address field of a browser:
10.10.10.200

* WiFi password of the wallbox (assigned during commissioning)

Access to the web admin of the controller wallbox


ABL

Wireless via WiFi-Router



Variant 1:

- Connection to the controller via network cable
→ Input in the address field of a browser:
`ablserialnumber.local`



Variant 2:

- Read out the IP address via the router interface



→ Enter the IP address in the address field of a browser

* WiFi password of the wallbox (assigned during commissioning)

ABL

ABL GmbH · Albert-Büttner-Straße 11 · D-91207 Lauf / Pegnitz
T. +49 (0) 9123 188-0 · info@abl.de · www.abl.de · www.ablmobility.de

© ABL GmbH 2024

Diese Präsentation und ihr Inhalt sind urheberrechtlich geschützt. Eine Vervielfältigung oder Veröffentlichung auch nur einzelner enthaltener Texte, Grafiken, Fotos ist strengstens untersagt und nur mit ausdrücklicher schriftlicher Genehmigung von ABL GmbH.

