

CONFIGURATION WITH NEW CONFIGURATION SOFTWARE

GROUP CONFIGURATION eMH3 TWIN

1	Follow preconditions
2	Press [Continue] button
3	Switch on last extender charging station
4	Wait 15 seconds
5	Press [Automatic Configuration] button
6	Extender charging station is displayed in delivery state (3/4)
7	Extender charging station is shifted to the next available address values (15/16)
8	Switch on next extender charging station
9	Wait 15 seconds
10	Press [Automatic Configuration] button
11	Extender charging station is displayed in delivery state (3/4)
12	Extender charging station is shifted to the next available address values (13/14)
13	Switch on controller charging station (only RCCBs!)

CONFIGURATION WITH NEW CONFIGURATION SOFTWARE

GROUP CONFIGURATION eMH3 TWIN

14	Wait 15 seconds
15	Press [Automatic Configuration] button
16	Controller charging station is displayed in delivery state (1/2), RFID address value stays empty
17	Controller charging station is shifted to the next available address values (11/12)
18	Press [Continue] button
19	Charging stations are shifted one by one to the front
20	Address configuration is completed, additional settings possible